

Gallay (R)

Gallay (L)

RD12  
RD11

RD14  
RD13

Upper

101 102 103 104 101 102 103 104 101 102 103 104 101 102 103 104 101 102 103 104 109 110 111 112 109 110 111 112 109 110 111 112 109 110 111 112 109 110 111 112  
105 106 107 108 105 106 107 108 105 106 107 108 105 106 107 108 105 106 107 108 113 114 115 116 113 114 115 116 113 114 115 116 113 114 115 116

SUS #4

81 82 83 RD9 84 85 86 RD9 87 88 89 90 91 92 93 94 RD 95 96 97 RD 98 99 100  
10 10

RD17  
Dir  
186  
185  
180  
179  
178  
177

RD18  
Dir  
188  
187  
184  
183  
182  
181

SUS #3

61 62 63 RD7 64 65 66 RD7 67 68 69 70 71 72 73 74 RD8 75 76 77 RD8 78 79 80

SUS #2


41 42 43 RD5 44 45 46 RD5 47 48 49 50 51 52 53 54 RD6 55 56 57 RD6 58 59 60

SUS #1

21 22 23 RD3 24 25 26 RD3 27 28 29 30 31 32 33 34 RD4 35 36 37 RD4 38 39 40

AP

1 2 3 RD1 4 5 6 RD1 7 8 9 10 11 12 13 14 RD2 15 16 17 RD2 18 19 20



Floor(R)

Floor (L)

125 126 127 128 129 130 131 132 133 134 135 136 137 138 139 140 141 142 143 144

Catwalk #1

RD 11




RD 11

Direct

Direct

RD 12

RD 12



145 146 147 148 149 150 151 152

153 154 155 156 157 158 159 160

Catwalk #2

Direct Direct

조명 회로도

객석 : CH 201, 202, 203, 204

Side front(R)

Side front(R)

118 120  
118 120  
117 119  
117 119

123 121  
123 121  
124 122  
124 122